

INSTALLATION INSTRUCTIONS:
Model:

4" IC Airtight -Remodeling Housing
R-F404S-R-ICA

Important:

Read all instructions before installing.

For installation by a qualified electrician.

System is intended for installation in accordance with National Electric Code, and local regulations. Consult with local inspector to assure compliance.

To reduce the risk of fire, electrical shock and injuries to persons, turn off power at main switch before installing or modifying the system.

Retain instructions for future maintenance reference.

Overview:

Remodeling housing suitable for direct insulation contact. Airtight rated. Trims ordered separately.

Cut Out:



1. Cut a 4 7/16" hole in the existing ceiling.
2. Pull ceiling wire through the hole.

Wiring:

1. Junction box is rated for branch wiring.
2. Open a knock out hole.
3. Remove spring latched junction box door and connect wires: White fixture wire to white building wire, black fixture wire to black (hot) building wire, and green ground wire to bare ground wire, with wire nuts supplied.
4. Replace junction box door.

Mounting:

1. Pivot the J box end up through the hole, followed by the can.
2. Hold the rim snug to the ceiling surface.
3. From inside the housing push and pivot the housing clips so they make contact with the top of the ceiling. Use fingers or a screwdriver applied to the push point to tension the spring.
4. Note: 3/4" maximum ceiling thickness.



Trim & Lamping

Trims:

1. To install trim, insert fully into housing. Three flat gripping springs will retain the trim. Open aperture trims allow the lamp to be installed after the trim is installed (diagram 1 & 2).
2. For closed aperture trims the lamp is installed first, followed by the trim.
3. Use CFL Tri-tube lamps 13W max (4 pin Gx24q base).

