

INSTRUCTIONS: 6" Series Horizontal Reflector Trims

Models: R6HT-21 R6HT-22 R6HT-23

Important:

Read all instructions before installing.

System is intended for installation in accordance with National Electric Code, and local regulations. Consult with local inspector to assure compliance.

To reduce the risk, electrical shock, turn off power at main switch before installing or modifying the system.

Retain instructions for future maintenance reference.

Overview:

Reflector Trims fit housings from the R6HF series. Consult catalog or spec sheet for compatibility.

Installing Trims:

1. Snap the spring loaded socket cup on to the side of the trim reflector.
2. Make sure the 4 retaining springs on the housing are in the inward position.
3. Push the reflector straight up until it is flush with the ceiling.
4. Insert the ends of the compact fluorescent lamps into the windows in the side of the reflector opposite the socket cup.
5. Align the compact fluorescent lamp base to the socket, and push in.
6. Insert baffles cross blades or other similar accessories, tapered end first. Reflectors have small spring cleats to hold fast.

