

INSTRUCTIONS:

Model: MANHATTAN FLUSH MOUNT

Read all instructions before installing.
Disconnect power before installing or re-lamping.
For installation by a qualified electrician.

HANGING THE FIXTURE

1. Carefully remove the fixture from the carton and check that all parts are included as shown in the illustration.
2. Shut off power at the circuit breaker and remove old fixture including the crossbar.
3. Support the weight of the fixture.
4. Feed power wire from the frame, up through the cross bar (B). Connect fixture wires to wires in the junction box with wire nuts.
5. Connect ground wire to the green grounding screw on the crossbar.
6. Attach the Crossbar (A) to the Outlet box in the ceiling with two screws (C). The side of the Crossbar with "GND" marked on it and two convex points must face out.
7. Slip the Fixture (E) up to the ceiling and lock in place by threading the screws (B) in the keyhole slots of the fixture. For additional support use Anchors (D) with Screws (F) into the ceiling.
8. Install the light bulb in accordance with the fixture's specifications. **(DO NOT EXCEED THE MAXIMUM WATTAGE RATING!)**
9. Attach the shade (I) to the fixture frame(E) by first installing the threaded rod (H) and lock with nut (G). Secure the glass bowl with Washer (J) Nut (K) cover Cap (L) and secure with Decorative Nut (M)
10. Your installation is now complete. Return power to the junction box and test the fixture.

