HR-8417

## WAC LIGHTING

Responsible Lighting®

## SAFETY INSTRUCTION

IMPORTANT: NEVER attempt any work without shutting off the electricity.


- Read all instructions before installing.
- For installation by a qualified electrician.
- System is intended for installation in accordance with National Electric Code, and local regulations. Consult with local inspector to assure compliance.
- To reduce the risk of fire, electrical shock and injuries to persons, turn off power at main switch before installing or modifying the system.
- Warning: (Risk of fire) do not install insulation within 3 inches of fixture sides, or junction box, or in a manner to entrap heat.
- Retain instructions for future maintenance reference.

## **OVERVIEW**

Trims fit housings from the HR-8000 series. Housing type and trim selection will determine maximum wattage; consult catalog or spec sheet for compatibility.

## INSTALLING LAMP AND TRIM:

- 1. From the front of fixture, insert the MR16 lamp followed by the clear glass lens, and secure with the lens retaining ring.
- 2. Push socket on to lamp pins.
- 3. Pressing the springs into the hole, until the trim ring is flush against the ceiling.
- 4. When relamping, take out the lens retaining ring and lens from the front of the fixture.
- 5. When changing transformer, turn the fixture clockwise and pull out.



**WAC Lighting** www.waclighting.com Phone (800) 526.2588 • Fax (800) 526.2585 Headquarters/Eastern Distribution Center 44 Harbor Park Drive • Port Washington, NY 11050 Phone (516) 515.5000 • Fax (516) 515.5050 **Western Distribution Center** 1750 Archibald Ave • Ontario, CA 91761 Phone (800) 526.2588 • Fax (800) 526.2585